




## IMPORTANT SAFETY INFORMATION

# INSTRUCTION GUIDE



**Read these instructions before using this product.**

**Failure to follow the instructions and safety precautions in this manual can result in serious injury or death.**

**Please keep this manual in a safe place for future reference.**



### **BURN AND FIRE HAZARD.**

Do NOT expose candle to water or other liquids.  
Liquids on hot wax can create spitting large flame.

Do NOT use water or other liquids to extinguish the flame. Use only the lid to extinguish and slide lid on from the side to avoid flame spreading.



### **BURN HAZARD.**

Fire pit and candle refill can produce flame up flames up to 3ft and hot liquid wax.


Do NOT touch or move the fire pit while fire pit is hot and candle has not completely solidified. Do NOT touch the drum while candle is burning or within one hour after extinguishing.







# IMPORTANT SAFETY INFORMATION

**For outdoor use only:** Use only in a well-ventilated area and place the fire pit and drum on a flat, stable surface on the ground at least 10 feet from any flammable surfaces, buildings or structures. Do not place on tables or other elevated surfaces.

**Do not use in the rain:**  **DANGER** Water and other liquids on hot wax will cause it to spit and pose a fire/hurn hazard. Do not use fire pit in the rain and do not use candle if it is wet.

**Extinguish properly:**  **DANGER** DO NOT USE WATER OR LIQUID TO EXTINGUISH THE FIRE. Only use the lid to extinguish the flame. Slide lid on from the side to avoid flames spreading – NEVER attempt to extinguish by placing lid from above. Do not remove the lid for at least one hour.

**Burn/fire risk:**  **DANGER** Fire pit and candle can produce an open flame up to 3 ft high and product hot liquid wax. Do not touch the drum while candle is burning or within one hour after extinguishing. Do not move fire pit while it is still hot and/or candle has not completely solidified. Never leave the fire pit unattended while lit or candle has not completely solidified.

**Not Safe for Food:** Do not use for cooking or heating foods or beverages.

**Candle Refills:** Fire Hazard. Do not add a new candle if any hot candle/melted wax remains or if more than 2 cm of solid candle remains. Do not use if candle is above the rim of the drum. Top of candle must be below the rim of the fire pit drum before ignition. Do not mix with other products as this may cause a chemical reaction.

**Adult supervision:** Adult use only. Keep out of reach of children and pets.

**Know the rules:** Check and follow local laws and regulations before use.

**Use correct candles:** Only use EcoFuego genuine candle refills. Do not use other types of candles or fuels.

**Label:** Do not remove the warning label on the outside of the fire pit.

**Proper Use:** Never use candle without the fire pit or without placing it in the drum.


**Use responsibly.** Use at your own risk. Do not use under influence of alcohol or drugs.

**Emergency instructions:** In case of fire or serious injury, call emergency services. For minor burns, cool the burn under running water and seek medical advice.

---


## INSTRUCTIONS FOR USE:

By following these instructions and safety precautions, you can enjoy your EcoFuego fire pit responsibly and safely.



### Stabilize the Fire Pit:

Place on the ground, if your fire pit comes with feet, screw them into the bottom to stabilize it, otherwise ensure fire pit is on a level and stable ground. EcoFuego Fire Pit bases can be purchased separately for additional stability.




### Insert Candle:

Keep candle in paper wrapping and insert into the drum without removing paper from candle.




### Prepare the Candle:

Carefully open and the top of candle paper and remove excess paper above the fire pit drum. **NOTE: Do not touch square, cardboard wick – wick is fragile and may be damaged if touched with items other than flame.**



### Ignite the Candle:

Light the exposed, square shaped wick with a match or lighter.




### Enjoy the moment!




### Extinguish Safely:

**⚠ DANGER DO NOT USE WATER OR LIQUID TO EXTINGUISH THE FIRE.** See Important Safety Information for instructions on how to slide lid on from the side to extinguish the flame.



**Cool Down:** Do not remove lid or touch fire pit after extinguishing flame for at least one hour. Allow to completely cool for at least one hour before placing fabric over the product.



### Use again and again:

The lighting/extinguishing process can be repeated each time you use the fire pit until the candle is used up.

## ECOFUEGO SAFETY PRECAUTIONS:

- **WARNING! Please read all instructions before use.**
- **Please use responsibly.** Use at your own risk. Do not use under influence of Alcohol, Drugs or Medication and keep out of reach of Children.
- **For outdoor use only:** Ensure you are in a well-ventilated area and place the drum on a flat, stable surface.
- **Do not use in the rain:** Water and other liquids on hot wax will cause it to spit and can be dangerous!
- **Stay safe:** Do not touch or move your fire pit while fire pit is still hot and candle has not completely solidified.
- **Extinguish properly:** Only use the lid to put out the fire. To extinguish slide the lid on from the side to avoid flames spreading. Do not attempt to extinguish by placing the lid on from above. Do not remove the lid once extinguished for at least 10mins.
- **Burn risk:** Be aware of the risk of burns. Do not touch the drum while candles are burning or immediately after extinguishing.
- **Handling:** Do not let the product fall or risk spillage during use. Do not place on high surfaces.
- Not for cooking or heating foods: Do not use to cook or heat food or liquids.
- **Candle refills:**
  - Do not add a new candle refill if any hot fuel remains.
  - Do not add a new candle refill if more than 2 cm of cold fuel remains.
  - Do not mix with other products as this may cause a chemical reaction.
- **Never leave unattended:** Do not leave the drum unattended while lit until the candle has solidified.
- **Adult supervision:** Adult use only. Keep out of reach of children and pets.
- **Avoid flammable items:** Keep away from flammable products and maintain safe distance, at least 10 feet from buildings or structures.
- **Open Flames:** Do not play or interfere with open flames.
- **Know the rules:** Check and follow local laws and regulations before use.
- **Use correct candles:** Only ever use EcoFuego genuine candle refills. Do not use other types of candles or fuels.
- **Label:** Do not remove the warning label on the outside of the fire pit.
- **Proper Use:** Do not use candle without the fire pit or the drum outside the fire pit.
- **Emergency instructions:** In case of fire or serious injury, call emergency services. For minor burns, cool the burn under running water and seek medical advice.

- **Proper disposal:** Dispose of used candles and wax residue according to local regulations. Do not pour hot wax down drains. Clean the drum regularly to remove wax buildup.


## TEAR RESISTANCE AND DURABILITY:

- **Material:** The fire pit is made from a composite called GFRC or types of steel/stainless steel, which withstands the extreme heat produced by the candle.
- **Cracks:** As with any ceramic fire pit and oven, extreme heat will cause cracks to appear, but these will not affect the unit's performance.
- **Protection:** The metal container on the upper rim protects the sides and helps keep the product clean.

## CANDLE TECHNICAL DATA:

- **Candle:** Vegetable biodegradable wax that emits a limited amount of smoke.
- **Storage Life:** 3 to 5 years in a dry place away from humidity.
- **Burn Time:** 6 to 8 hours for a full-size refill and 3-5 hours for a half-size refill subject to temperature, altitude, and wind.

## MAINTENANCE:

- **Cover:** Cover when not in use and once cooled.
- **Storage:** Store in a cool, dry place with the lid securely in place.
- **Protection:** Cover the fire pit when not in use, especially in the event of rain or frost.
- **Cleaning:** Clean the surface once cool. Wipe with a clean, damp cloth. Clean the inside of the fire drum every 3 refills to remove residues.
- **Winter Storage:** The EcoFuego fire pit is designed for year-round use in dry weather. Coat the rim of the metal fire drum with petroleum jelly or a suitable oil before storing to prevent rust formation.
- **Using after storage:** Check there is no water sitting on or around the candle before re-using. If water is present remove the remaining candle from the drum, dry the drum thoroughly and replace candle.
- ** DANGER** Water and other liquids on candle will cause hot wax to spit and pose a fire/burn hazard.


## FREQUENTLY ASKED QUESTIONS:

### Is the fire pit suitable for use on terraces and lawns?

Yes. The EcoFuego fire pit obviously gets very hot and must be placed on a heat-resistant surface on the ground or EcoFuego fire pit base (may be sold separately) to prevent it from affecting the surface on which it is placed. Please refer to detailed instructions for use.

### Is it easy to turn off?

Yes. Simply slide the lid back over the flame to cover the fire drum. The flame will go out immediately.

 **DANGER NEVER EXTINGUISH WITH WATER OR OTHER LIQUID.** Once lid has been placed do not remove for at least one hour.

### Will the candle remain solid or turn to liquid?

Once lit, the top part of the candle will melt and become hot liquid. Do not spill or move the container when candle is in the liquid state as it is extremely hot. The wax will return to a solid approx. 40 mins after being extinguished.

### When should I replace the refill?

We recommend you let the candle burn out completely and there is no wax left. Please remember to thoroughly clean the fire drum once the refill wax has completely burnt out and then insert the new refill. To prevent the candle from breaking, DO NOT remove the paper wrap. Only the top part of the paper should be removed to light the candle.

### Can candle refills be used on their own?

No! Using refill candles on their own poses a fire/burn hazard. Refills must ONLY be used with the EcoFuego fire pit drum and surround.

### Can I find out more about the wax?

The wax is vegetable-based, biodegradable and comes from sustainable sources. We source from audited and recommended suppliers.

### Can I touch my fire pit?

Fire pits should not be touched while burning.

Once the candle flame has been extinguished, you should wait at least an hour before touching the fire pit with bare hands. Always maintain a safe distance from flammable and heat-sensitive materials.

### How do I clean my fire pit?

After the fire pit has completely cooled, clean the surface with a clean, damp cloth. For thorough cleaning, especially the inside of the fire drum, it is recommended to clean it every 3 refills to remove residues. Ensure all wax residue is properly disposed of according to local regulations.

### Can I leave my EcoFuego fire pit outside?

Cover the fire pit when not in use and store it in a cool, dry place with the lid securely in place. Whilst the fire pit is designed for outdoor use, covering it helps protect it from rain, frost, and other weather conditions to promote longevity.

### What kind of refills should I use?

Only use genuine EcoFuego refills, which are recommended for the EcoFuego fire pit. NEVER use other types of candles or fuels, as they may cause unexpected flare-ups or hazardous conditions. Always insert candle refills without removing paper wrapping and follow the provided instructions for safe usage. If hot wax remains or if more than ¾ of an inch (2 cm) of cold wax remains, do not insert a new candle refill.

### Can I make my own refill?

No. Using non-specified candles can lead to safety hazards, including unexpected flare-ups, excessive smoke, or damage to the fire pit. Always use EcoFuego genuine candles refills recommended by the manufacturer to ensure safe and efficient operation.

### Do I have to burn the EcoFuego wax refill all in one go?

NO. Although each wax refill can burn for a few hours, you do not have to burn it all at once. Unlike conventional fire pits, you can light (and extinguish) as often as you like until the candle is all used up. Simply LIGHT, HEAT (enjoying the warm of the fire pit, then slide the lid on when finished) and REPEAT.

# HAVING ISSUES WITH YOUR FIRE PIT?

---

## IS YOUR REFILL NOT LIGHTING? YOU MAY HAVE A FLOODED WICK...

Does your fire pit have a small flame like this?



Scan below for instructions to solve this issue.



---

## HAS YOUR REFILL BEEN BROKEN OR DAMAGED IN TRANSIT?

Occasionally, due to the nature of this product and transportation method, your fire pit refill may arrive broken. Despite this the refills are still good to burn, the wax is fine. If still possible, keep in wrapping paper. If not, follow these instructions:



### WHAT TO DO IF REFILL IS BROKEN?

- Step 1:** Collect the broken pieces together for the next lighting. Don't throw them away.
- Step 2:** Place the broken pieces on the outside of the wick to melt when lit, adding more burn time to your candle.
- Step 3:** Make sure not to let them sit on the wick! This could put it out.



VISIT OUR WEB SITE FOR MORE  
TIPS AND INFORMATION.  
[ECOFUEGO.COM](http://ECOFUEGO.COM)

CONTACT US

PHONE: +1 (305) 831 1195

EMAIL: [SALES@ECOFUEGO.COM](mailto:SALES@ECOFUEGO.COM)

